






## Getac PS236 input method setting

Refer to the below procedure to set the input method.



Double click the XT9 program and install it on Getac. Then you will see the icon  when entering.



if you want to enter the letters just change the entering mode to letter mode and then hide the soft keyboard by clicking  and then you can enter the letters.